

There are 2 keys in the front panel for controlling the light level.

1. A brief press on "+" or "-" key will start an automatic fade up to a 100% or fade down to a 0% light level.

2. If either keys are pressed for more than 1.5 seconds then the light level will be adjusted manually for as long as the key is pressed at 4 preset (0%, 25%, 75%, 100%) levels.

3. The dimmer will cut off the light in following situations:

- a. The load exceeds 80W.
- b. In 12V system, voltage < 9V or > 16V.
- c. In 24V system, voltage < 19V or > 30V.

The LED next to "+" or "-" key will flash depend on the above situations.

