

FOOTSWITCHES

DOWN


UP

Black

Green

Black

Red



Black connector

Green connector

+
Battery
-

Fuse
5 A

ROCKET SWITCH TYPE C



- 8 - Black connector
- 2- Battery +
- 3 - Green Connector